



MTN/MH010

Mounting Stud Adhesive

Description

A 2-part adhesive suitable for mounting all of Monitran's range of the mounting studs. It has a working life of 4 minutes. Each tube secures approx 25 Studs.

Application Instructions

1. Ensure surface is properly prepared – clean, dry and free from grease & oil.
2. Cut tip of syringe end.
3. Dispense required amount and mix thoroughly to an even colour. (Max time 1-2 Minutes)
4. Apply to mounting
5. Seal tip with plug provided. (Located in centre of plunger)
6. After 30 minutes the product is workable with hand tools.

Health and safety

CAUTION! Contains epoxy resin
Can be irritating to eyes and skin.
Wash hands with soap and water.